

Alexa FAQ for Control4 Homeowners

Q: How do I connect an Amazon Alexa device to my Control4 Smart Home?

A: Read the *Alexa Quick Start Guide* (ctrl4.co/alexa-help) or watch the *Connecting Amazon Echo to Control4* video (ctrl4.co/alexa-videohelp) to learn how to connect your Amazon Alexa device to your Control4 Smart Home.

Q: What Amazon Alexa devices will work with my Control4 Smart Home?

A: The Echo Dot (including 3rd Gen), Echo (including 2nd Gen), Echo Plus (including 2nd Gen), Echo Spot, Echo Show (including 2nd Gen), Fire TV Stick 4K, Fire TV Stick, and Fire TV Cube.

Q: Do all Control4 systems work with Alexa devices?

A: You need a 4Sight subscription for your Control4 system to work with Alexa. Also, the system must be running Control4 OS 2.8.2 or greater.

Q: In what countries can I use the Control4 Smart Home Skill?

A: You can use the Control4 Smart Home Skill in Australia, Austria, Canada (English and French), England, France, Germany, India, Ireland, Italy, Mexico, New Zealand, Scotland, Spain, and the US.

Q: If I don't already have an Amazon account, where do I go to create one?

A: Create an Amazon account at your region-specific Amazon site, listed below. Or, if you have an account already, you can change your country settings in your Amazon account settings.

Country	Website
Australia	alexa.amazon.com.au
Austria	alexa.amazon.de
Canada	alexa.amazon.ca
England	alexa.amazon.co.uk
France	alexa.amazon.fr
Germany	alexa.amazon.de
India	alexa.amazon.in
Ireland	alexa.amazon.co.uk
Italy	alexa.amazon.it
Mexico	alexa.amazon.com.mx
New Zealand	alexa.amazon.com.au
Scotland	alexa.amazon.co.uk
Spain	alexa.amazon.es
US	alexa.amazon.com

Q: What devices in my Control4 Smart Home will I be able to control using voice commands?

A: Initially, you can use voice commands for all your lights, lighting scenes, thermostats, locks, fans, room volume, and video devices. You can control more items in your house by contacting your dealer to set up whole-home scenes for you.



Q: Can I change the name of my device or scene for easier voice control?

A: Yes. Log in to customer.control4.com and select **Amazon Alexa** under *Automation*. Here you can edit the device name for voice control. This will change the name for only voice control—all your touch screens, on-screen Navigators, and Control4 apps for your mobile devices will display the original name. Details on this process can be found in the *Alexa Quick Start Guide* (ctrl4.co/alexa-help) or *Customizing Alexa devices and scenes* (ctrl4.co/alexa-scenehelp).

Note: Devices with a possible duplicate name are marked with a red warning icon.

Q: What voice commands can I use with my Control4 Smart Home?

A: To get a personalized list of commands you can use with your system, log in to customer.control4.com and select **View Voice Commands** in the *Amazon Alexa* section. Below is a general sample of the commands you can use:

Lights	Scenes
<i>Alexa, turn on Kitchen Lights</i>	<i>Alexa, turn on House</i>
<i>Alexa, turn off Kitchen Lights</i>	<i>Alexa, turn off House</i>
<i>Alexa, set Master Lamp to 50%</i>	Video devices
<i>Alexa, increase Master Lamp by 10%</i>	<i>Alexa, turn on Living DVD</i>
<i>Alexa, decrease Master Lamp by 20%</i>	<i>Alexa, turn off Living DVD</i>
Thermostats	<i>Alexa, play on Living DVD</i>
<i>Alexa, set Upstairs Thermostat to 72 degrees</i>	<i>Alexa, pause on Living DVD</i>
<i>Alexa, increase Upstairs Thermostat by 3 degrees</i>	<i>Alexa, play next on Living DVD</i>
<i>Alexa, decrease Upstairs Thermostat by 2 degrees</i>	<i>Alexa, play previous on Living DVD</i>

Q: Why are the changes I made on customer.control4.com not showing up in the Alexa app?

A: After saving the changes on customer.control4.com, you need to ask Alexa to discover devices for them to be available in your Alexa app.

Q: I disabled a device on customer.control4.com and asked Alexa to discover devices, but the disabled device is still showing in the Alexa app as offline. How do I get this removed from the Alexa app?

A: Go into the Alexa app and disable the device and ask Alexa to discover devices again.

Q: Are there any tips on naming devices or scenes?

A: It is best to use simple one- or two-word descriptions using house and room names where appropriate. For example: Dining Light, Office Lamps, All Lights, House, Upstairs Thermostat, Accent Lights, Master Lights.

Q: What names of devices or scenes should I not use?

A: Do not use numbers in device names like Kitchen 1 Light. Make sure each device and scene name is unique to your system and all names are spelled correctly. Avoid using "On" or "Off" as part of the device or scene name.

Q: Can I use more than one Alexa device with my Control4 System?

A: Yes, they will all be able to accept the same voice commands, but it is preferable to have them separated so that they do not hear the same voice commands.



Q: How does auto mode on the Control4 thermostat work with Alexa?

A: The Control4 thermostat has both a heat and a cool set point. When you ask Alexa to increase the temperature by two degrees or set the temperature to 72 degrees while in Auto mode the Control4 thermostat will do the following:

- If it is currently cooling the house, it will change the cool set point and check the heat set point to see if it needs to be adjusted.
- If it is currently heating the house, it will change the heat set point and check the cool set point to see if it needs to be adjusted.

Q: I created a lighting scene on my touch screen and everything worked. I then added another device to the lighting scene. Now, when I turn on the scene the added device turns on, but when I turn off the scene the added device does not turn off. How do I fix this?

A: If you add a device after you create a lighting scene, you will also need to add the device to the toggle lighting scene to have it turn off.

Q: Where do I go to get more information?

A: More Information can be found at ctrl4.co/alexa-help.